

KONAN[®]

CATALOG
No. **2309E**


URL=<http://www.konan-em.com/>

LINE COMPONENTS



KONAN ELECTRIC CO.,LTD.


KONAN LINE COMPONENTS



"For both safety and savings..."

"The rising needs for automation and labor saving are satisfied by each member of the lineup, from general purpose types, where importance is given to basic performance, to specialized types designed for individual industries and applications"

This booklet shows groups of line controls necessary for adequate operation of solenoid valves, cylinders, etc.
 Select the type best suited to your system by carefully examining the specifications.
 For those other than contained here, please feel free to contact us.



Directional Control Valves

● Solenoid Valves

For details, refer to separate "Solenoid valves" catalogue.



Four-Port Hand-Operated, Directional Control Valves 80

- Standard type ----- PVT1 PVT406K PVT410K
- With locking mechanism - - PVT1M
- Lower-piping type ---- PVT1L PVT406L PVT410L



Silencers 86

- Resin-made type ----- ES3
- Metal-made type ----- ES4
- With throttle valves ---- EVS4 EVS5 EVS6



Exhaust Filters 93

- Standard type ---- KMFC2



Manifold Filters 96

- Standard type ----- MF2



Speed Controllers 98

- Standard type ----- SC6 SC213
- Fine-tuning type ---- SC6F



Omnidirectional, Screwed Speed Controllers 104

- Standard type ----- SC7



Omnidirectional, One-touch Speed Controllers 107

- M3·M5·Rc1/8·1/4·3/8·1/2



Check Valves 113

- Standard type ----- CV3



Pilot-Operated Check Valves 116

- Standard type ----- CVP2



Shuttle Valves 118

- Standard type ----- CVT3



Quick-Release Valves 121

- Standard type ----- QEV3



Safety Block Valves 125

- Standard type ----- CVD1



Lockup Valves 127

- Standard type ----- LVS5 LVD5



Quick cylinder extension preventive valves Slow-Start Valves 130

- Standard type ----- SSV2



Pressure Detecting Valves 133

- Standard type (3Ports) --- PSV5
- Standard type (5Ports) --- PSV2
- Low pressure ----- PSV3L purpose (5Ports)




One-Touch Couplers Touch Connectors 137

- M5×0.8·Rc1/8·1/4·3/8·1/2



Touch tubes 144

- ϕ 4·6·8·10·12mm



I	N	D	E	X	PAGE
	Air Filters				5
	Air Filters with Autodrain				13
	Regulators				17
	Regulators with External Pilot				26
	Precision Regulators				29
	Regulators for 0.02 to 0.2MPa				34
	Electric Regulators				39
	Volume Boosters				42
	Lubricators				51
	Forced Spray Micromist Lubricators				58
	FRL Units				61
	FR Units				67
	Reducing valve with filter				73
	Four-Port, Hand-Operated Direction Control Valves				80
	Silencers				86
	Exhaust Filters				93
	Manifold Filters				96
	Speed Controllers				98
	Omnidirectional, Screwed Speed Controllers				104
	Omnidirectional, One-touch Speed Controllers				107
	Check Valves				113
	Pilot-Operated Check Valves				116
	Shuttle Valves				118
	Quick-Release Valves				121
	Safety Block Valves				125
	Lockup valves				127
	Slow-Start Valves				130
	Pressure Detecting Valves				133
	One-Touch Couplers Touch Connectors				137
	Touch Tubes				144


AIR FILTERS

Drain fluids in the pneumatic lines may increase piping corrosion resistance, and hinder the function of controls in the line, finally lead to accidents. Be sure to use air filters to remove drain fluids from the line and prevent problems.

AF2/AF21	Standard type	Rc $\frac{1}{8}$ ~ 100A
----------	---------------	-------------------------

AF2P/AF21P	Panel-mount type	Rc $\frac{1}{4}$ ~ 1
------------	------------------	----------------------

JIS Symbol



Model Code

When ordering, specify the model as follows:

Standard type

Rc $\frac{1}{8}$ ~ $\frac{1}{4}$

AF2 -02 - 2 - 10

• Port size

• Bracket

Rc $\frac{1}{4}$ ~ $\frac{1}{2}$

AF21 1 -04 - 3 - 7 - 8 - 10

• Corrosion-resistant

• Port size

• Operating temperature range

• Filter rating of element

• Bracket

Rc $\frac{3}{4}$ ~ 1

AF2 1 -08 - 4 - 7 - 8

• Corrosion-resistant

• Port size

• Operating temperature range

• Filter rating of element

Rc $1\frac{1}{4}$ ~ 2

AF2 1 - 5 - 7 - 8 - 9 - 10

• Corrosion-resistant

• Port size

• Operating temperature range

• Filter rating of element

• Level gauge

• Bracket

Rc $2\frac{1}{2}$ ~ 100A Flange

AF2 - 6

• Port size

Panel-mount type

Since these models are for panel mounting, drain cock are not installed but a female thread are tapped for piping. Please set up drain valve separately.

Rc $\frac{1}{4}$ ~ $\frac{1}{2}$

AF21P 1 -04 - 3 - 7 - 8 - 10

• Corrosion-resistant

• Port size

• Operating temperature range

• Filter rating of element

• Bracket

Rc $\frac{3}{4}$ ~ 1

AF2P 1 -08 - 4 - 7 - 8

• Corrosion-resistant

• Port size

• Operating temperature range

• Filter rating of element

① Corrosion-resistant

- Portions that are exposed to outside weather conditions are corrosion-resistant coating and the exposed bolts,nuts and brackets are stainless steel.

Standard	No entry
Corrosion-resistant type	S

② Port size

Rc 1/8	6A
Rc 1/4	8A

③ Port size

Rc 1/4	8A
Rc 3/8	10A
Rc 1/2	15A

④ Port size

Rc 3/4	20A
Rc 1	25A

⑤ Port size

Rc 1_1/4	32A
Rc 1_1/2	40A
Rc 2	50A

⑥ Port size

Rc 2_1/2	65A
80A Flange	80A
100A Flange	100A

⑦ Operating temperature range

General purpose	- 20 ~ 60°C	No entry
Heat-resistant	5 ~ 100°C	HT
Freeze-resistant	- 40 ~ 45°C	LT

- For corrosion.freeze resistant type,allow some margin for delivery.
- In operating temperatures of 5°C or less, provide adequate measures against freezing.
- Please note that no freeze-resistant are manufactured for filters with a Rc2 port size.

⑧ Filter rating of element

General purpose	40 μm	No entry
Instrumentation	5 μm	5

- For the miniature type,note that a filter rating of 5 microns only is available.

⑨ Level gauge

Without	No entry
Flont side	F
Back side	B

⑩ Bracket

Without	No entry
With	BR

- Bracket is not mounted but appended with air filters.



AIR FILTERS

Specifications

Model code	Standard type	AF2-02	
Port size		6A	8A
		Rc1/8	Rc1/4
※1 Effective sectional area		7mm ² Filter rating=5μm	
Operating pressure		0 ~ 1MPa	
Proof pressure		1.5MPa	
Operating temperature		- 20 ~ 60°C	
Mass		0.19kg	

Model code	Standard type	AF21-04			AF2-08		AF2					
	Panel-mount type	AF21P-04			AF2P-08							
Port size		8A	10A	15A	20A	25A	32A	40A	50A	65A	80A	100A
		Rc1/4	Rc3/8	Rc1/2	Rc3/4	Rc1	Rc1 1/4	Rc1 1/2	Rc2	Rc2 1/2	Flange	Flange
※1 Effective sectional area	General purpose	40mm ²	68mm ²	90mm ²	171mm ²	190mm ²	480mm ²	655mm ²	1060mm ²	1450mm ²	1800mm ²	2500mm ²
	Instrumentation	28mm ²	30mm ²	40mm ²	76mm ²	77mm ²	190mm ²	190mm ²	300mm ²	—	—	—
Operating pressure		0 ~ 1.0MPa										
Proof pressure		1.5MPa										
Operating temperature		See Model Code section.						- 20 ~ 60°C				
Mass		0.58kg	0.62kg	0.6kg	12.0kg			22.0kg	28.0kg	39.0kg	50.0kg	


● Above values of mass exclude weight of mounting bracket.

● For specifications other than those listed above, please contact us.

※ 1. Effective area shown when : inlet pressure 0.5MPa pressure drop (ΔP) 0.05MPa

Operation

Standard type



1 Deflector

Changes air under pressure from IN port into a rotating flow and separates moisture from the air centrifugally.

2 Filter element

Filters out lightweight dirt, foreign matter, etc. that cannot be separated from the air centrifugally.

3 Bowl

Drain separated centrifugally runs down the inner wall of the bowl and collects at the bottom.

4 Baffle plate

Prevents drain at the bottom of the bowl's from mixing with the air again.

5 Side glass

Used to see how much drain has collected.


6 Drain cock

Turning the handle counterclockwise allows drain to be discharged.

Outside Dimensions


Standard type

AF2-02-6A · 8A




Panel-mount type


AF21-04-8A · 10A · 15A




AF21P-04-8A · 10A · 15A



AF2-08-20A · 25A



AF2P-08-20A · 25A






AIR FILTERS


Outside Dimensions

Standard type


AF2-32A • 40A




AF2-80A




AF2-50A



AF2-100A



AF2-65A




Performance Tables


Flow characteristics graphs (filter grade=40 μm)

Standard and Panel-mount type


AF21-04-8A




AF2-08-20A




AF2-32A




AF21-04-10A




AF2-08-25A




AF2-40A




AF21-04-15A




AF2-50A




AF2-65A



AF2-80A



AF2-100A






AIR FILTERS

Performance Tables


Flow characteristics graphs (filter rating=5 μ m)

Standard and Panel-mount type


AF2-02-6A-8A




AF21-04-8A




AF2-08-20A




AF21-04-10A



AF2-08-25A




AF21-04-15A




Performance Tables

Flow characteristics graphs (filter rating=5 μ m)


AF2-32A



AF2-40A



AF2-50A




Operating Instructions

1 Discharging drain fluid

AF2-02

- Push up the push rod of the drain valve.




Standard / Corrosion-resistant type

- Turn the handle of the drain cock counterclockwise; the pressure in the bowl will cause the drain to be discharged.




Panel-mounted type

- A Rc1/8 thread is machined in the body. Connect the drain discharge pipe or tube to this thread.




Rc1_1/4 and above type

- Open the stop valve; the pressure in the bowl will cause the drain to be discharged.



2 Installation

- Install the air filter as far as possible from the air source.
- Leave room so that the bowl can be removed and the filter.



- Install the air filter and lay the pipe so that the drain port is located at dead bottom.


AIR FILTERS

with Autodrain

ADF2/ADF21 Standard type $R_c \frac{1}{4} \sim 2$

An automatic drain has been fitted to the air filters. This separates and removes drain from the pneumatic line, thus preventing trouble.

JIS Symbol



Model Code

When ordering, specify the model as follows:

Standard type

$R_c \frac{1}{4} \sim \frac{1}{2}$

ADF21 1 - 04 - 2 - 5 - 6

• Corrosion-resistant • Port size • Filter rating of element • Bracket

$R_c \frac{3}{4} \sim 1$

ADF2 1 - 08 - 3 - 5

• Corrosion-resistant • Port size • Filter rating of element

$R_c 1\frac{1}{4} \sim 2$

ADF2 1 - 4 - 5 - 6

• Corrosion-resistant • Port size • Filter rating of element • Bracket

① Corrosion-resistant

- Portions that are exposed to outside weather conditions are corrosion-resistant coating and the exposed bolts,nuts and brackets are stainless steel.

Standard	No entry
Corrosion-resistant type	S

② Port size

Rc 1/4	8A
Rc 3/8	10A
Rc 1/2	15A

③ Port size

Rc 3/4	20A
Rc 1	25A

④ Port size

Rc 1_1/4	32A
Rc 1_1/2	40A
Rc 2	50A

⑤ Filter rating of element

General purpose	40 μ m	No entry
Instrumentation	5 μ m	5

⑥ Bracket

Without	No entry
With	BR

- Bracket is not mounted but appended with air filters.


Specifications

Model code		ADF21-04			ADF2-08		ADF2		
Port size		8A	10A	15A	20A	25A	32A	40A	50A
		Rc1/4	Rc3/8	Rc1/2	Rc3/4	Rc1	Rc1 1/4	Rc1 1/2	Rc2
Effective sectional area	General purpose	40mm ²	68mm ²	90mm ²	171mm ²	190mm ²	480mm ²	655mm ²	1060mm ²
	Instrumentation	28mm ²	30mm ²	40mm ²	76mm ²	77mm ²	190mm ²		300mm ²
Operating pressure		0 ~ 1.0MPa							
Proof pressure		1.5MPa							
Operating temperature		- 20 ~ 60℃ (For use below 5℃ ,provide adequate measures against freezing.)							
Mass		0.86kg		0.9kg	0.88kg		14.8kg		24.8kg

- Above values of mass exclude weight of mounting bracket.
- For specifications other than those listed above,please contact us.




Operation




- 1 If sufficient drain fluid, separated out by the filter, collects in the float case, the inner and outer floats rise under the buoyancy of the drain.
- 2 The inner float pushes up the piston while the outer float presses the outer ring of the piston and the seal on the lower part of the upper lid. Thus, air flow between chambers A and B is shut off.
- 3 As air is consumed in this condition, a pressure differential occurs between chambers A and B. If the differential rises above 10%, the piston rises further, and the bottom valve is opened, allowing drain fluid to discharge. After drainage, the pressures in chambers A and B equalize, and the piston descends, closing the bottom valve.
- 4 Therefore, if air is consumed intermittently under the control of a solenoid valve, the air filter works well. Below an operating air pressure of 0.05MPa the upward forces from the buoyancy of both floats automatically causes the piston to rise, the bottom valve to open, and the drain to be discharged, whether or not there is a pressure difference present between the chambers. Pressing the pushbutton for manual discharge opens the bottom valve and causes the drain to be discharged, regardless of the operating air pressure.

Outside Dimensions

ADF21-04-8A • 10A • 15A




ADF2-08-20A • 25A




Outside Dimensions

ADF2-32A • 40A



ADF2-50A



Operating Instructions


1 Installation

- Installation point


Install as far as possible from the air source and free risk of impact.

- Bowl removal dimension

- ① Leave room so that the bowl can be removed and the filter element checked.
- ② Install the air filter and piping so that the drain port is located at dead bottom.



2 Discharging drain fluid



- Drainage conditions

- ① When the pressure in the bowl falls 10% or more below the air supply pressure from the operation, of peripheral devices.
- ② When the air supply pressure is 0.05MPa and below.
- ③ When the pushbutton for manual discharge is pressed.