

RW-MULTI8-FUJI

Externes USB2-Laufwerk für Fujisoku 38-Pin Karten

Beschreibung

Das RW-MULTI8-FUJI Laufwerk kann Fujisoku 38-Pin SRAM Karten lesen und beschreiben.

Das Laufwerk wird am PC über USB angeschlossen mit dem mitgelieferten Kabel. Es nimmt den benötigten Strom vom USB – kein externes Netzteil nötig.

Im Lieferumfang enthalten ist auch eine CD-ROM mit Windows Software zur Wiedergabe, Editierung, Lesen und Schreiben der Daten.

Dieses robuste Schreib/Lese Gerät ist nur als externes Laufwerk mit Metallgehäuse erhältlich.

Typische Anwendungen

- Sicherung der auf einer Fujisoku Karte enthaltenen Daten
- Offline Vorbereitung der Daten vor der Übertragung auf die Speicherkarte.

Installation

Die PC Software, die auf der CD-ROM enthalten ist, sollte erst installiert werden, bevor das RW-MULTI8-FUJI am USB-Port des Computers angeschlossen wird.

Die komplette Beschreibung der Installation und Anwendung dieses Fujisoku-Laufwerks ist im „User's Manual“ enthalten.



Technische Eigenschaften

Physical	
Dimensions	118mm x 105mm x 32mm
Weight	215 g
Card Slot	Single, without ejector-button
Operating Temp.	0°C to 70°C

Card Support	
General	38-Pin Fujisoku and ITT-Canon STAR memory cards
Writing	SRAM 32KByte bis 1Mbyte (For Flash or EPROM please contact supplier)
Reading	ROM, EPROM, FLASH, OTP

Electrical	
Supply	5VDC via USB Port
Power	0,5 VA
Data	USB

Platform & Operating-System	
Computer	IBM PC-kompatible, mit USB Port
Windows	Win98, Win98SE, WinME, Win2000, WinXP