


Vapor Pressure Sensor (VPS), Ex - Safety Information

General

Each part of the system is marked with a label. The label has important EX Safety data and also identifies the part.

Vapor Pressure Sensor (VPS)



The label is placed on the VPS.

EX - Data



II 1G EEx ia IIC T4 Ta: -40 to 80°C
NEMKO 01 ATEX 162