



Accessories

[BT06k \(/en/accessories/bt06k\)](#) | [BT024IK \(/en/bt024ik\)](#) | [CB70 \(/en/accessories/cb70\)](#) | [LA70 M \(/en/accessories/la70m-la70x\)](#)

BT06k

Battery for Handheld Pushbutton Transmitters T70/1 and T70/2

The BT06K model battery is a rechargeable NiMH (Nickel Metal Hydride) battery for use with pushbutton transmitters from the TM70 range (models T70/1 and T70/2).

The capacity of the batteries decreases with use. Their estimated life is 500 charge cycles, but this depends largely on the conditions of use, so we recommend the following:



- Do not recharge the battery until it is fully discharged. The transmitter will tell you when it is time.
- Charge the batteries at temperatures of 0–45°C (at higher temperatures, the batteries will not charge fully). Avoid placing the charger in direct sunlight.
- Charge the batteries at least once every six months.
- Avoid shorting the battery contacts. Do not carry charged batteries in a toolbox or in pockets with other metal parts (keys, coins, etc.).
- Keep the contacts clean.
- Do not expose the batteries to sunlight.

SPECIFICATIONS

Model	BT06K
Type	NiMH
Capacity	600 mAh, 4.8 V
Charging temperature range	0 to 40°C
Weight	70.3 g